

iKASU™



Mini MP3 Player

After Sales Support

Tel - 0161 975 0458

Web support – www.fascin8.co.uk

Table of Contents	1
Safety and Upkeep	2
Functions.....	3
Accessories	4
Instructions	5-6
Frequently Asked Questions	7
Technical Specifications	8
Technical Support	9

- Never attempt to fix the player yourself by opening and disassembling the unit as this will affect your guarantee.
- Do not expose the player to direct sunlight for long periods of time.
- Do not expose the player to damp or moist conditions
- When the player is not in use turn the player off to preserve the battery charge.
- This player uses a Lithium battery. When the player no longer functions it will need another 4 hour charge



Do not dispose of this product in your household waste. Contact your local authority for details of local recycling schemes

Main functions

- This player will play audio in the following formats – MP3
- The player has a built on clip which you can use to attach to your belt, clothes etc



1 USB Connection Cable




1 Set of Headphones



1 Software Disk

Connecting to a PC

Before connecting your MP3 player to your PC, please make sure that the player is ON. Using the USB cable attach one end to the MP3 player and one end to your USB port on your PC and at the bottom right corner of the PC, a symbol  will appear, this means that your MP3 player is now connected and ready to use. From here simply go into “my computer” and you should see the new device.

Power Supply Operation**ON/OFF**

Switch the power switch from the “off” to the “on” position, the player will turn on automatically.

Charging

This player uses a rechargeable lithium battery, its is recommended that you charge the player for at least 4 hours in the ON position before you attempt to use it in any way.

Connect the USB cable provided to the player and then to the PC the player will start charging.

Music Playback

In order to place music on your MP3 player simply copy and paste your MP3's into the removable device which should appear when you plug your MP3 player in, then unplug your MP3 player from the PC.

If you are trying to get music from a CD onto your MP3 player then simply put your music CD into your PC and open up windows media player (if you do not have this then you can download the software from the microsoft website) using the RIP facility, RIP the songs from your CD to the MP3 player. If you unsure on how to do this either use the windows media help or alternatively go to www.fascin8.co.uk and watch the video tutorial which will give you step by step instructions.

Once you have placed music into your MP3 player switch on the MP3 player and you will then see a red light flash once then pause then flash twice then pause again and finally flash one more time from within the unit, only after these flashes can you then press play.

In order to change the volume press either the + OR – button on the player.

To pause the song press the play button again.

Question

Why wont my songs play on my MP3 player but will play on my PC?

My player wont stay on and keeps turning off.

My PC wont display the MP3 driver.

Answer

Check that your songs are in the correct format (MP3) in which the player will play.

Make sure you have given the player a full 6 hour charge and check your power off settings.

Check by using other USB slots on your PC also try using a separate USB cable as cables can also be faulty.

Item	Specification
Speed	USB 2.0 full speed (Read1000K Byte/s,Write750K Byte/s)
Headphone output	(L) 10mW + (R)10mW (32 ohm)
Memory	Built-in Flash
Battery life	approx. 7hours
Working temperature	-5°C - 40°C
System requirement	Windows ME/2000/XP、 Mac OS 10.3、 Linux 2.4.2 and Windows 98 (please refer to driver installation details)

TECHNICAL SUPPORT LINE

GENERAL SUPPORT CAN BE PROVIDED ON ALL
PRODUCTS PURCHASED FROM US

(Unfortunately we cannot provide support on products or components that we do not supply)

0161 975 0458

Calls cost National Rate, Unless dialling from 0161 area

CALLERS MUST BE MINIMUM OF 18 YEARS OF AGE

CALLERS MUST HAVE THE PERMISSION OF THE TELEPHONE SUBSCRIBER

ALL INFORMATION GIVEN IS CORRECT
AT THE DATE OF PUBLICATION - 23/02/2007

HOURS OF BUSINESS

MON – FRI 9am to 5pm (excludes bank holidays)

FASCIN8 LTD
14 EMBANKMENT BUSINESS PARK
VALE ROAD, HEATON MERSEY
STOCKPORT CHESHIRE, SK4 3GN

Alternatively visit our website for further support
www.fascin8.co.uk