



USB Audio Video Converter

VHS/Camcorder to DVD

After Sales Support

Tel - 0161 975 0458

Web support – www.fascin8.co.uk

Model No:AV-820

Table of Contents	1
Safety and Upkeep	2
Functions and System Requirements	3
Accessories	4
Instructions	5-8
Frequently Asked Questions	9
Technical Specifications	10
Technical Support	11

- Never attempt to fix the device yourself by opening and disassembling the unit as this will affect your guarantee.
- Do not expose the device to direct sunlight for long periods of time.
- Do not expose the device to damp or moist conditions
- Do not throw into a naked flame.



Do not dispose of this product in your household waste. Contact your local authority for details of local recycling schemes

Main functions

- Records Video streaming from both Video Camera and VCR.
- Picture slide show and edit
- DVD cinema player with frame snap shot.



1 USB Extension Cord



1 Software Disk



1 Quick Ref Guide


Installing the drivers

In order to connect the device to your PC, please take the following steps

1. Plug the device into your USB slot on your PC.
2. Insert the provided CD into your disk drive.
3. You will then see the below box appear



4. Select “No, not this time” and then select Next.
5. You will now see the following box appear.



6. You will now start to see the drivers install onto your PC.
7. If you get a pop up box asking to select between two drivers, select the first one for XP and the second for 2000 (it will display xp and 2k at the end of each driver selection)

Installing AV8TO software

Once you have installed the driver you must now install the software provided on the CD.

In order to do this please follow the below steps.

1. Go into your disc drive and open the SETUP.EXE file then simply follow the on screen instructions to install the software. Once you have finished installing we recommend you reboot your PC if it has not already ask you to do so.

Recording from a Device

Now that you have installed the drivers and the software you are ready to start recording, you can record from the following devices.

- DVD players
- Video Cameras (most video streaming with AV out function)
- Video players (VCR must have a AV connection)

In order to start recording from your chosen device simply plug a AV cable from the 3 connection points on the USB grabber device and then into the AV slots on the chosen device or if you have a device with a AV out then you will need a AV cable with the correct connection jacks.

Now start up the AV8TO software, you will now see the below appear.



Before you start recording make sure that your settings are correct, to enter the setup click on the setup button. Go through the settings and make sure that each setting is set to your desired requirements.



If you are recording via S-Video and not AV then simply click the switch video source button to change the input.



You can also change the format in which the file will be recorded into, in order to change the format click on the record format button and select as desired.



You are now ready to start recording, press play on the device you are attached to and when you see a screen displayed on your PC press the record button to begin the transfer.



Once you have finished recording press the stop button and the movie will now be saved into your C:\Video. You can replay the movie by pressing the playback button, this will now display all recorded files you have done, to play one select and press play. To come out of the play back press the exit button.

You can also take a snap shot of the movie which is playing by pressing the take snap shot button, this Will then save the file into C:\Pictures or you can view them by pressing the browse image button and selecting this path.



Question

Why cant I see any display when plugging in the AV

It wont record anything when I press record

The USB device does not seem to be working correctly.

Answer

Check that the AV cables have been put into the correct slots on both ends.

Check that there is enough space on the drive in which the videos are being saved to.

Make sure the drivers are installed if in doubt reinstall.

- IBM PC or compatible
- Intel Pentium 4 2.0GB MHz / equivalent AMD Athlon™ CPU or better processor
- One available USB2.0 port.
- Minimum 256 MB memory of RAM or more
- Minimum 100 MB hard disk space available
- 1024x768 graphic card, DirectX R 9.0c or above compatible graphic card or higher
- Microsoft Windows XP HOME/PRO EDITION /XP 64bit
- CD-ROM drive
- Hard Disk: 5400 RPM or above (7200 RPM preferred)

TECHNICAL SUPPORT LINE

GENERAL SUPPORT CAN BE PROVIDED ON ALL
PRODUCTS PURCHASED FROM US

(Unfortunately we cannot provide support on products or components that we do not supply)

0161 975 0458

Calls cost National Rate, Unless dialling from 0161 area

CALLERS MUST BE MINIMUM OF 18 YEARS OF AGE
CALLERS MUST HAVE THE PERMISSION OF THE TELEPHONE SUBSCRIBER

ALL INFORMATION GIVEN IS CORRECT
AT THE DATE OF PUBLICATION - 23/02/2007

HOURS OF BUSINESS
MON – FRI 9am to 5pm (excludes bank holidays)

FASCIN8 LTD
14 EMBANKMENT BUSINESS PARK
VALE ROAD, HEATON MERSEY
STOCKPORT CHESHIRE, SK4 3GN

Alternatively visit our website for further support
www.fascin8.co.uk